



Notes About Steam Models with Holiday Sounds :

Broadway Limited Imports has created a special soundset for your new Holiday-themed steam locomotive. Out of the box, the sounds and sound functions will differ from a typical Broadway Limited Imports steam engine. View default sounds of your new model in the chart below:

| | |
|------------------------------------|---------------------------------------|
| F1: Sleigh Bells | F15: No function |
| F2: Santa Claus Message | F16 – F19: Elf Chatter |
| F3 (Reading T1): Christmas Song #1 | F20: Elf Workshop Sounds |
| F4: Christmas Song #2 | F21: Christmas Theme Lumber Sounds |
| F7 (Pacific): Christmas Song #1 | F23 (Pacific): Reindeer Hooves |
| F7 (Reading T1): Smoke on/off | F23 (Reading T1): Short Whistle Blast |

Other notes about the holiday sounds:

- CV158 controls the volume of both songs. Value range is 0-255. 255 is maximum volume.
- To hear only the Christmas sounds: set cv's 137–155 to a value of 0. Then set CV199=0.

If you want the sounds on your model to function like a typical Paragon4 steam engine, change the following CV's:

| | |
|---|--|
| CV223 = 1 (for normal train bell) | CV36 = 17 (F3 Coupler Sounds) (Reading T1) |
| CV224 = 1 (for standard whistle) (or press F22) | CV40 = 21 (F7 becomes inactive (Pacific)) |
| CV37 = 5 (F4 plays air pump sounds) | |

**** DC Master AUX buton is smoke control by default on the Reading T1 ****

Music Credits:

Jingle Bells: Kevin MacLeod (incompetech.com) Licensed under Creative Commons: By Attribution 3.0 License <http://creativecommons.org/licenses/by/3.0/>

We Wish you a Merry Christmas: Kevin MacLeod (incompetech.com) Licensed under Creative Commons: By Attribution 3.0 License <http://creativecommons.org/licenses/by/3.0/>