



Operation:

Your new Lightning & Thunder accessory creates a realistic thunderstorm on your layout, or wherever you choose to use it. It produces authentic thunderstorm sounds and the LED strips flash in time with the thunder to simulate lightning strikes lighting up the sky. The device has two modes - Manual Mode and Automatic Mode. Manual mode is always on. Manual Mode means the device will be completely silent unless you press the push-button. When you press the button in Manual Mode, you will immediately hear a loud thunderclap accompanied by alternating lightning strikes. Once that sequence is complete, the device will go back to silent until you or a friend press the button again. When you have the Lightning & Thunder accessory set to Automatic Mode, you will see and hear a complete 90 second thunderstorm, with lightning strikes, play in its entirety at random intervals between five seconds and five minutes. Note that Manual Mode is still active when the device is set to Automatic Mode. You can still use the button to trigger an immediate thunder clap and lightning strike anytime. To toggle between only Manual Mode or Automatic Mode, press and hold the push-button for two seconds. After two seconds, the LED strips will flash once or two times. One flash indicates Manual Mode. Two flashes indicates it is set to Automatic Mode.



Warranty Information:

This model is warranted against defects in materials and workmanship for a period of one year from the date of purchase. In the event you require service, please contact us using the SUPPORT tab of our website: www.broadway-limited.com.